

## **FORKLIFT RULES**

- 1) Do not operate this forklift without authorization and training card/certificate.**
- 2) Inspect this forklift before use. Report defects, malfunctions and damage. Remove forklift from service until repairs are completed.**
- 3) Do not drive up to anyone standing in front of a bench or other fixed object.**
- 4) Do not allow personnel to stand or pass underneath the forks.**
- 5) Do not carry passengers on this forklift.**
- 6) Keep hands, arms and legs inside this forklift at all times.**
- 7) Do not leave this forklift until the boom is lowered, controls are neutralized, power is off and wheels are blocked when parked on an incline.**
- 8) Set brakes and block wheels of vehicles while loading and unloading.**
- 9) Check the floor of trailers and trucks before entering.**
- 10) Check overhead clearance before lifting a load.**
- 11) Do not raise or lower loads during travel.**
- 12) Sound horn when backing, entering a blind corner or blind intersection.**
- 13) If load obstructs forward view, travel with the load trailing behind.**
- 14) Loads shall be carried as low as possible and tilted only enough to stabilize.**
- 15) Unstable loads shall be secured before travel.**
- 16) Do not exceed the rated capacity of this forklift.**
- 17) Use load backrest and extensions when the load could fall backwards.**
- 18) Do not lift personnel without use of safety cage and belt.**