

## Programming Device IDs

You should only program your ResponseCard to a different Device ID if requested to do so. For more information, contact Turning Technologies toll-free at 1.800.746.3015 or email [support@turningtechnologies.com](mailto:support@turningtechnologies.com).

### ResponseCard NXT

- 1 Press the **key** under the Wrench icon.
- 2 Use the **right arrow** to scroll to Device Info and press the **Enter/center button**.
- 3 Press the Channel button, the Channel button, the ABC button and finally the Enter/center button.
- 4 Enter the new six-digit Device ID using keys '0' to '9' (valid Device IDs are 000001 to 999999). *Entering '000000' will reset the Device ID to factory default.*
- 5 Press the **soft key** under OK.

